

CONEL Ltd.

2140, Ботевград, ул. "Бенковски" 27 /партер/

conel-m@botevgrad.com



Layout Keys	TV set	
	HARMAN KARDON AVR156_8444	
	Function's	Shift
POW	PowerOff	PowerOff
1	1	DVD
2	2	CD
3	3	Tape
4	4	VID1
5	5	VID2
6	6	TV
7	7	HDMI1
8	8	HDMI2
9	9	HDMI3
-/--	Direct	DIRECT
0	0	AUX1
P/C	AM/FM	AUX2
VOL+	VOL+	VOL+
AV	PowerOn	PowerOn
CH+	Preset+	Preset+
VOL-	VOL-	VOL-
MUTE	MUTE	MUTE
CH-	Preset-	Preset-
MENU	SPKR.	SPKR.
EXIT	CLEAR	CLEAR
TEXT		
TV/DTV		
BACK	CH.	CH.
UP	Up	^
I+	OSD	OSD
LEFT	Left	Left
OK	OK	OK
RIGHT	Right	Right
....	Digital	Digital
DOWN	Dn	v
INFO	Delay	Dealy
RED	Tun.M	Tun.M
GREEN	Tun.Dn	Tun.Dn
YELLOW	Memo	Memo
BLUE	Tun.Up	Tun.Up
<I	RDS	RDS
=?	TEST	TEST
size	Night	Night
Stop		
SLEEP	SLEEP	SLEEP
SOUND	TONE	TONE
PICT.	DIM	DIM

