

CONEL Ltd.

2140, Ботевград, ул. "Бенковски" 27 /партер/

conel-m@botevgrad.com



Layout Keys	TV set	
	HARMAN KARDON AVR7000_7087	
	Function's	Shift
POW	PowerOff	PowerOff
1	1	DVD
2	2	CD
3	3	Tape
4	4	VID1
5	5	VID2
6	6	VID3
7	7	VID4
8	8	
9	9	
-/--	DIRECT	DIRECT
0	0	
P/C	AM/FM	6 CH.
VOL+	VOL+	VOL+
AV	PowerOnAVR	PowerOnAVR
CH+	Preset+	Preset+
VOL-	VOL-	VOL-
MUTE	MUTE	MUTE
CH-	Preset-	Preset-
MENU	SURR.	SURR.
EXIT		
TEXT	Delay	Delay
TV/DTV	MultiRoom	MultiRoom
BACK	CH.	CH.
UP	Up	∧
I+	SPKR	SPKR.
LEFT	Left	Left
OK	SET	SET
RIGHT	Right	Right
....	Digital	Digital
DOWN	Dn	∨
INFO	OSD	OSD
RED	Tun.M	Tun.M
<<	Tun.Dn	Tun.Dn
>	Memo	Memo
>>	Tun.Up	Tun.Up
=x	CLEAR	CLEAR
=?	TEST	TEST
size	Night	Night
PAUSE		
SLEEP	SLEEP	SLEEP
SOUND		
PICT.		

