

CONEL Ltd.

2140, Ботевград, ул. "Бенковски" 27 /партер/

conel-m@botevgrad.com



Layout Keys	TV set	
	HARMAN KARDON Model:AVR132_8914	
	Functions	Shift
POW	PowerOff	PowerOff
1	1	DVD
2	2	CD
3	3	Tape
4	4	Bridge
5	5	HDMI1
6	6	TV
7	7	VID1
8	8	VID2
9	9	CBL/SAT
-/--	Direct	DIRECT
0	0	VID3
P/C	AM/FM	6 CH.
VOL+	VOL+	VOL+
AV	PowerOn	PowerOn
CH+	Preset+	Preset+
VOL-	VOL-	VOL-
MUTE	MUTE	MUTE
CH-	Preset-	Preset-
MENU	DolbySurr.	SURR.
EXIT	DTS Surr.	DTS Surr.
TEXT	NEO 6	NEO 6
TV/DTV	Logic 7	Logic 7
BACK	CH.	CH.
UP	Up	Up
I+	SPKR	Info
LEFT	Left	Left
OK	OK	OK
RIGHT	Right	Right
....	Digital	Digital
DOWM	Dn	Dn
INFO	Delay	Dealy
RED	Tun.M	Tun.M
GREEN	Tun.Dn	Tun.Dn
YELLOW	Memo	Memo
BLUE	Tun.Up	Tun.Up
<I	CLEAR	CLEAR
I>	TEST	TEST
size	Night	Night
Stop	RDS	Dimmer
SLEEP	SLEEP	SLEEP
SOUND	TONE	TONE
PICT.	Stereo	Stereo

