

CONEL Ltd.

2140, гр.Ботевград ул. Бенковски #27 (партер)

conel-m@botevgrad.com



Layout Keys	Brand:SONY Model:STR-DE197_8936
	Code Name
POWER	Power
MODE	
DISP.	
MUTE	Mute
V+	Volume+
PRESET/SLEEP	Sleep
P+	Ch./Preset+
V-	Volume-
DIMMER	
P-	Ch/Preset-
FUNC.	
UP	Bass +
CLEAR	
LEFT	Treble-
OK	D.Tuning/Enter
RIGHT	Treble+
>10	>10/Shift
DOWN	Bass -
T.MODE/EQ	
1	1
2	2
3	3
BASS	Bass Boost
4	4
5	5
6	6
TREBLE	
7	7
8	8
9	9
0	0
TIMER	
CLOCK	
REP.	
SHUFF.	
R+	
F+	
C+	
L/R+	Ball. R
Input	Vid.1
Output	Vid.2
C-	
L/R-	Ball.L
RED/CD	CD
GREEN/Tape	Tape
YELL./AUX	DVD
BLUE/TUNER	Tuner

