

CONEL Ltd

2140 Ботевград, ул.Бенковски 27 /партер/

conel-m@botevgrad.com



Layout Keys	Brand:YAMAHA Model:AX-570_9602
	Functions
POWER	Power
MODE	Phono
DISP.	
MUTE	Mute
V+	Volume+
PRESET/SLEEP	Sleep
P+	Tun.Pr.+
V-	Volume-
DIMMER	
P-	Tun.Pr.-
FUNC.	Tape2
UP	Tun.Pr.+
CLEAR	
LEFT	Volume -
OK	A/B/C/D/E
RIGHT	Volume +
>10/INFO	
DOWN	Tun.Pr.-
T.MODE/EQ	EQ
1	
2	
3	EQ+
BASS/TV	
4	
5	
6	EQ-
TREBLE/BACK	
7	
8	
9	
0	
TIMER	
CLOCK	
REP.	
SHUFF.	
REC.	
PLAY	CD >
STOP	CD II / stop
PAUSE	CD II / stop
FAST REWIND	I<<
FAST FORWARD	>>I
REWIND	<<
FORWARD	>>
RED/CD	CD
GREEN/Tape	Tape1
YELLOW/AUX	AUX
BLUE/TUNER	Tuner

